


HEATER ON / OFF




Push for heater ON / OFF

Heater ON led steady

Temp. led blinking slow


SAUNA ROOM LIGHT ON / OFF



Push for light ON / OFF

Light ON led indicator

SET SAUNA ROOM TEMPERATURE



Push to select temperature

Temperature led steady or blinking slow

Hold down to activate select.

Temperature led blinking fast

Push to increase temperature


Push to decrease temperature

Push long to confirm

OR

After 5 sec. auto confirm

SET SESSION TIME



Push to select session time

Session time led steady

Hold down to activate select.

Session time led blinking fast

Push to increase session time

Push to decrease session time

Push long to confirm

OR

After 5 sec. auto confirm